



Torque tester Torque tester from 0,2 until 5 Nm.

- Tester for screwdriver calibration
- 3 units of torque measurements
- Automatic shut down
- 2 Display mode selectable
- Battery powered or power supply

WTT5 Torque tester from 0,2 until 5 Nm

- Tester for screwdriver calibration
- 3 units of torque measurements
- · Automatic shut down
- 2 Display mode selectable
- Battery powered or power supply

Product information



WTT5

Code No.: T0058767706